

Android Tip Strip

What is "wifi"?

Wi-Fi (wireless fidelity) is a popular technology that allows an electronic device to connect to the Internet wirelessly using radio waves.



How do I connect?

1 From your tablet's home screen, tap the "Settings" picture.



2 When the settings menu pops up, tap "Connections"




3 "Choose a Network" by tapping a network name*



*If you see a lock next to the network name, you will need a password to connect to that network.

On/Off?

To turn the tablet on/off, find the button on the side and press. To unlock, slide your finger across the screen.



Black Screen?

If the screen goes blank, press the "home" button (on the front of the tablet.)



Then slide the arrow to the right.

Too big to see?

Make what you see on the screen smaller by placing your fingers on the screen and slide them together.



Not what I ordered!

If what you see on the screen is unexpected or unwanted and won't go away, press the "back" button.



iPad Tip Strip

What is "wifi"?

Wi-Fi (wireless fidelity) is a popular technology that allows an electronic device to connect to the Internet wirelessly using radio waves.



How do I connect?


① From your tablet's home screen, tap the "Settings" picture.



② When the settings menu pops up, tap "Wi-Fi"



③ "Choose a Network" by tapping a network name*



*If you see a lock next to the network name, you will need a password to connect to that network.

On/Off?

To turn the iPad on/off, find the long button on the side and press. Then put your finger on the picture of the arrow and slide it to the right.



Black Screen?

If the screen goes blank, press the "home" button (on the front of the iPad.)



Then slide the arrow to the right.

Too big to see?

Make what you see on the screen smaller by placing your fingers on the screen and slide them together.



Not what I ordered!

If what you see on the screen is unexpected or unwanted and won't go away, press the "home" button and start over.



Kindle Tablet Tip Sheet

What is "wifi"?

Wi-Fi (wireless fidelity) is a popular technology that allows an electronic device to connect to the Internet wirelessly using radio waves.



How do I connect?

1 From your tablet's home screen, slide your finger down from the top to see settings.



2 When the settings menu appears, tap "Wi-Fi."



3 "Choose a Network" by tapping a network name*



*If you see a lock next to the network name, you will need a password to connect to that network.

On/Off?

To turn the Kindle on/off, find and press the power button on the side



Search the Internet

To search the Internet, tap in the box on top where it says "Search"



Go back to the previous screen



If a screen pops-up that you don't want, tap the little circle at the bottom of the screen

Go back to "home"

To start over, tap the little circle at the bottom of the screen

